



BELT ASSEMBLY 4

RF VERSION

BY STRUMFETT

STEP 9 : — — — — —
PUT THE BELT BETWEEN THE TEMPLATE AND AND PIE-
CE OF WOOD. USE THE DRILL WITH METAL DRILL BIT TO
MAKE THE HOLES.



STEP 10 : — — — — —
MAKE THE SEWINGS (SEE TEMPLATES) AND PUT THE
GROMMETS.



FINISHED !