



## BELT ASSEMBLY 4

RF VERSION

BY STRUMFETT

### STEP 9 :

PUT THE BELT BETWEEN THE TEMPLATE AND AND PIECE OF WOOD. USE THE DRILL WITH METAL DRILL BIT TO MAKE THE HOLES.



### STEP 10 :

MAKE THE SEWINGS (SEE TEMPLATES) AND PUT THE GROMMETS.



FINISHED !