




# FLAP ASSEMBLY

RF VERSION

BY STRUMFETT


## STEP 6:

USE TEMPLATE 4 TO CUT THE LOCKING TAB.



## STEP 7:

AGAIN, USE TEMPLATE 1 TO CUT THE TWO SLITS ON THE FLAP.  
USE WHITE PENCIL OR ANOTHER COLOR (DEPENDS ON COLOR OF THE BACKSIDE OF THE MATERIAL) TO MARK THE LOCATION OF THE TAB.



## STEP 8:

REMOVE TEMPLATE 1 AND GLUE THE LOCKING TAB USING WHITE MARKS .

